

ET&F Fastening Systems, Inc.

29019 Solon Rd.,
Solon, OH 44139

Ph: 440-248-8655 * 800-248-2376
Fax: 440-248-0423 * www.etf-fastening.com

MODEL 610 SPARE PARTS LIST

When ordering spare parts, please state the part name and number.

Item#	Part #	Description	Qty	Item#	Part #	Description	Qty
1	610-949755	Hex Socket HD.Bolt	1	57	610-981317	O-ring	1
2	610-880515	Plate	1	58	610-880672	Valve piston (B)	1
3	610-880514	Top Cover	1	59	610-878925	O-ring	2
4	610-878854	Hex Socket HD. Bolt	4	60	610-878887	O-ring	1
5	610-882158	Exhaust cover	1	61	610-878884	Plunger spring	1
6	610-878919	Gasket (B)	1	62	610-881778	Plunger (B)	1
7	610-878912	Spring	1	63	610-878888	O-ring	1
8	610-878913	O-ring	1	64	610-880671	Valve bushing (A)	1
9	610-878911	Head Valve	1	66	610-872645	O-ring	1
10	610-878372	O-ring	3	67	610-880128	Feed Piston	1
11	610-878918	Head valve rubber	1	68	610-876796	O-ring	1
12	610-878915	Exhaust valve rubber	1	69	610-877144	Feed spring	1
13	610-880513	Retaining ring	1	70	610-880129	Shift lever	1
14	610-874104	Cylinder O-ring	1	71	610-877827	Feed piston cover (A)	1
15	610-880512	Cylinder plate	1	72	610-877713	Feed piston cover	1
16	610-878961	O-ring	1	73	610-949819	Hex Socket HD.bolt	2
17	610-880735	Cylinder	1	74	610-877479	Magazine bushing	1
18	610-878931	Piston ring	1	75	610-877360	Magazine bushing	1
19	610-880127	O-ring	1	76	610-877371	Nylon nut	1
20	610-880730	Piston (H)	1	77	610-880133	Magazine bushing	1
21	610-955479	Retaining ring	1	78	610-872971	Retaining ring	2
22	610-881006	Body Ass'y	1	79	610-877149	Stopper spring	1
23	610-878933	Piston bumper	1	80	610-880146	Magazine stopper	1
24	610-874436	O-ring	1	81	610-877150	Stopper pin	1
25	610-880121	Washer	1	83	610-876465	Nylan nut	1
26	610-880731	Nose	1	84	610-880666	Holder shaft	1
27	610-993068	Nylock high tension bolt	4	85	610-880398	Ratchet spring	1
28	610-949685	Roll Pin	1	86	610-880665	Nail holder	1
29	610-878339	Needle roller	1	87	610-880704	Magazine cover	1
30	610-949770	Roll Pin	1	88	610-877152	Hinge pin	1
31	610-878132	Feeder arm	1	89	610-949423	Washer	1
32	610-878340	Feeder spring	1	90	610-949230	Machine screw	1
33	610-880140	Feeder	1	91	610-880703	Magazine Ass'y	1
34	610-876676	Safety spring	1	92	610-877826	Feeder shaft ring	1
35	610-880733	Pushing lever (B)	1	93	610-880495	Guide lock	1
36	610-880497	Nail guide shaft	1	94	610-880446	Spring	1
37	610-881974	Adjuster	1	95	610-880732	Nail Guide	1
38	610-982454	Spring	2	96	610-949496	Roll Pin	1
39	610-959155	Steel ball	2	97	610-880493	Nail Stopper (A)	1
40	610-880130	Pushing lever (A)	1	98	610-880494	Stopper spring	1
41	610-880081	Washer	1	99	610-880124	Nail stopper (B)	1
42	610-949657	Hex socket HD. bolt	1	100	610-880125	Nail guide cover	1
43	610-881768	Grip tape (A)	1	101	610-880126	Cover	1
44	610-880407	Tape	2	102	610-878614	Nylock hex HD. socket	1
45	610-880183	O-ring	1	130	610-878337	Sleeve	1
46	610-883590	Cap	1	131	610-880413	Nylock hex HD.socket	1
47	591	Air plug	1	501	610-880132	Nose Cap	1
48	610-880734	Machine screw	1	502	610-877153	Pneumatic tool lubricant	1
49	610-949864	Roll Pin	1	503	610-875769	Eye protector	1
50	610-949865	Roll Pin	2	504	610-944459	Hex bar wrench	1
51	610-881779	Trigger (A)	1	505	610-944458	Hex bar wrench	1
52	610-881771	Trigger pin	1	506	610-943277	Hex bar wrench	1
53	610-880361	Pushing lever guide	1		610-BRKT	Bracket	1
54	610-877699	Head valve O-ring	1		610-NUT	Weld nut	1
55	610-878881	Valve bushing (B)	1		610-LPKM	Magnetic nose	1
56	610-878885	O-ring	1		610-PAD	Delrin Pad	1
					610-SK	Seal Kit	1
					610-STAB	Stabilizer	1